

## K03 VX CARBINE KIT

### 1) Folding the stock :

**To fold Stock , press the circled area until you can push the stock right hand side and fold , when you reach the end you will hear a click sound to confirm its been locked in fold position . To Unfold Stock simply reverse the step above.**



### 2) To Adjust the Rear sight:

**Area marked 1 is where you can flip the sight into either a standard iron sight or a Ghost Ring sight as seen in picture below. Area marked 2 is where you can adjust the screw to control elevation level of the rear sight.**



### 3) How to House the VX pistol into the carbine kit:

The VX carbine kit currently can house the VX1 / VX2 pistols (and its WE / TM Standard or Compact size counter part models) exception to this are the new VX7 / VX9 pistols (unless you are willing to file down the lower frame beaver tail area and trigger guard area etc to fit ) . In order to house the pistol , first fold the stock to the folded position mentioned in point 1), then turn the kit to the bottom area and take the key circled Red out of the key slot.



### 4) Taking the lower receiver out to house the VX pistol:

To house the VX pistol the kits lower receiver must be taken out by using the Key (1) to unscrew area (2). Once done pull the lower Receiver out completely (3).



**5) Fitting VX pistol inside kit:**

**Simply put pistol in slot and push forward and you will hear a small “click” sound.**



**6) Make sure the trigger guard area of the pistol is locked in place of the kit.**





**7) Finish installing VX pistol to kit :**

**To finally finish the install process of the pistol , reverse step 4 and push the lower receiver back to the end of the kit shown in (1) and screw tight the screw at the back. Then test slide function on (2) by pulling the charging handle and release. Now good to go for test firing.**

