



| No. | Name of Parts | QTY. |
|-----|------------------------------|------|
| 1 | Back Strap | 1 |
| 2 | Barrel Base | 1 |
| 3 | Chamber Sleeve | 1 |
| 4 | Frame | 1 |
| 5 | Hammer | 1 |
| 6 | Hammer Base Left | 1 |
| 7 | Hammer Base Right | 1 |
| 8 | Hammer Block | 1 |
| 9 | Inner Barrel | 1 |
| 10 | Magazine Bottom | 1 |
| 11 | Magazine Catch | 1 |
| 12 | Magazine Release Bar | 1 |
| 13 | Magazine Release Button | 1 |
| 14 | Mechanical Frame Left | 1 |
| 15 | Mechanical Frame Right | 1 |
| 16 | Muzzle Cap | 1 |
| 17 | Nail | 1 |
| 18 | Nail Arm | 1 |
| 19 | Nail Arm Lift | 1 |
| 20 | None | 0 |
| 21 | Outer Barrel | 1 |
| 22 | Puncture Adjuster Screw Knob | 1 |
| 23 | Puncture Frame Left | 1 |
| 24 | Puncture Frame Right | 1 |
| 25 | Puncture Screw | 1 |
| 26 | Puncture Screw Click Plunger | 1 |
| 27 | Red Dot | 1 |
| 28 | Safety Lever Left | 1 |

| No. | Name of Parts | QTY. |
|-----|-------------------------------------|------|
| 29 | Safety Lever Right | 1 |
| 30 | Safety Lock | 1 |
| 31 | Safety Plunger | 1 |
| 32 | Safety Unlock Button | 1 |
| 33 | Sear | 1 |
| 34 | Slide Block | 1 |
| 35 | Slide Stop | 1 |
| 36 | Trigger | 1 |
| 37 | Trigger Bar | 1 |
| 38 | Trigger Bar Plunger | 1 |
| 39 | Trigger Base | 1 |
| 40 | Buffer Spring | 2 |
| 41 | Hammer Block Spring | 1 |
| 42 | Hammer Spring | 1 |
| 43 | Magazine Catch Spring | 1 |
| 44 | Magazine Eject Spring | 1 |
| 45 | Nail Arm Lift Spring | 1 |
| 46 | Nail Arm Spring | 1 |
| 47 | Nail Base Spring | 1 |
| 48 | None | 0 |
| 49 | Puncture Screw Click Plunger Spring | 1 |
| 50 | Safety Lock Spring | 1 |
| 51 | Safety Plunger Spring | 1 |
| 52 | Sear Spring | 1 |
| 53 | Slide Return Spring | 1 |
| 54 | Trigger Bar Plunger Spring | 1 |
| 55 | Trigger Spring | 1 |
| 56 | Flat Head Pin ϕ 2x11 D4x1 | 1 |

| No. | Name of Parts | QTY. |
|-----|---|------|
| 57 | Flat Head Pin ϕ 3x23.5 D3.5x0.5 | 2 |
| 58 | Knurling Pin ϕ 2x20 | 1 |
| 59 | Pin ϕ 2x12.5 | 1 |
| 60 | Pin ϕ 3x8 | 1 |
| 61 | Straight Knurling Pin ϕ 2.5x13 | 2 |
| 62 | Flat Head Tap Tight Screw S-type 2.6x6 | 2 |
| 63 | Pan Head Tap Tight Screw S-type 2.6x8 | 4 |
| 64 | Pan Head Tap Tight Screw S-type 2x6 | 1 |
| 65 | Pan Head Tappig Screw A-type 2.6x8 | 1 |
| 66 | Pan Head with Collar Tap Tight Screw S-type 2x4 | 2 |
| 67 | None | 0 |
| 68 | Spring Pin 2.5x22 | 1 |
| 69 | Spring Pin 3x20 | 1 |
| 70 | Spring Pin 3x26 | 1 |
| 71 | Spring Pin 4x20 | 1 |
| 72 | Valve Body | 1 |
| 73 | O-Ring P-6 Urethane | 1 |
| 74 | Washer | 1 |
| 75 | Valve Spring | 1 |
| 76 | Valve Pin | 1 |
| 77 | Valve Seal | 1 |
| 78 | Valve Cap | 1 |
| 79 | Valve Ring | 1 |
| 80 | O-Ring P-5 1A | 1 |
| 81 | Pierce Pin | 1 |
| 82 | Pierce Seal | 1 |
| 83 | Pierce Cap | 1 |
| 84 | Slide Assembly | 1 |
| 85 | Magazine | 1 |