




Twist open the screw and pull it out



▲ Pull out the plug and remove the bracket




▲ Close the buckle and place the red circle around it



SNOW WOLF

SW-028

INSTRUCTION



**FOR AGES
18 YEARS AND UP**

Always read through this manual before operation.

⚠ WARNING



Only for 18 years of age or older

Operation of this air gun for competition use is restricted to users of 18 years of age or older.



Injury caution

Since plastic BB bullets reach so to 60 meters, careless shooting may cause eye damage or other injuries.




Careful reading of Handling cautions and Instruction manual

Always read through this HANDLING CAUTIONS AND INSTRUCTION MANUAL carefully before operation. Operate the air gun with full recognition of warnings and cautions.

R REGULATION



When shooting the Airsoft Gun for a target or game, you and all participants must wear goggles or other eye protective gear, also paying attention to ricochets. (Pay sufficient attention also to third personnel other than participants.)




Never aim or shoot a person or animal as the target. Always attach the protective plug to the muzzle, except when you are ready to shoot a target.




You may be punished if you are shooting for a practical joke.



Avoid pulling the trigger carelessly.




Never shoot the Airsoft Gun at places where people and cars pass cross.





Always direct the muzzle towards a safe direction.




Always put the Airsoft Gun in a case or bag when you are carrying it.




Store the Airsoft Gun at places out of reach by children






BB bullets may be shot out even if the magazine is removed.




Release and put away your fingers from the trigger, except when you are ready to shoot a target.



Never look into the gun muzzle.




Never disassemble or modify the Airsoft Gun.




**PRODUCT DECOMPOSITION
DIAGRAM**

SW-028


MADE IN CHINA



◀ Dismantling of magazine




▲ Disassemble the rear cover and insert the battery



◀ Pull to the middle point, turn on the switch and fire

● BB bullet regulator

Adjust hop-up to keep the BB could shoot more far in the horizontal direction shootin



Rotation adjustment

Hop-up (could be do 11 ymove)