

USER MANUAL FOR VICTOPTICS SVD SCOPE

EYEPIECE FOCUSING

The eyepiece is designed to provide a precise fast focus at certain eye relief. The eyepiece will focus faster than your eye can compensate for any inaccuracy in your adjustment.

MAGNIFICATION ADJUSTMENT (IF APPLICABLE)

To change magnification, simply turn the power selector ring, choose the desired power depending on the shooter's preference, and align the number with the index dot. Lower magnification provides a wider field of view and a brighter image. It is helpful in low-light, close-range shooting, and moving targets.

Higher magnification should be reserved for precise long-range shooting, which has a narrower field of view and dimmer image.

MOUNTING


The scope has a detachable mount that will fit a side dovetail rail placed on the left side of your rifle. The mounting procedure consists of the following steps:

- ① Loosen the mount clamp by turning the latching lever to its extreme outer position.
- ② Slide the scope onto the side dovetail rail. Move it forward towards the barrel until it reaches the stop position.
- ③ Turn the lever to tighten and lock the clamp. Make sure that the lever is latched into its initial home position and won't come off spontaneously.




①

Loosen the mount clamp by turning the latching lever to its extreme outer position.



②

Slide the scope onto the side dovetail rail. Move it forward towards the barrel until it reaches the stop position.



③

Turn the lever to tighten and lock the clamp. Make sure that the lever is latched into its initial home position and won't come off spontaneously.



ZEROING

The scope features finger-adjustable audible-click elevation and windage adjustments. Referring to the point of impact you will need to adjust both windage and elevation turrets. The elevation is the vertical (up and down) adjustment, usually on the top of the scope. Windage is the horizontal (left-to-right) adjustment, usually on the right of the scope.

With the scope mounted, rest the firearm onto a solid support and aim at a target 100 yards away. Slowly shoot a small 3 to 5 round test group onto your target. Adjust windage & elevation screws in the direction you want to move the bullet impact.

Should your impacts be below your point of aim, dial UP to reach zero. Should your impacts be left to your point of aim, dial R(right) to reach zero. Each click of adjustment moves the point of impact. Shoot another 3 to 5 round test group. Repeat until you are satisfied with the point of aim.

TURNING ON & ILLUMINATION ADJUSTMENT

Placed under the scope, the illumination adjustment knob controls the intensity level. It lights up all or a portion of the reticle. The scope has 3 intensity levels red. Toggle the switch to turn on the illumination. Toggle the switch to “OFF” will turn the illumination off.

BATTERY EXCHANGE

Your scope illumination is powered by 1 piece of CR2032 lithium button battery. To insert, remove or replace the battery: Release the battery compartment cover. Remove the used battery from the battery compartment. Insert a new one from a reputable manufacturer with the positive (+) side UP. Screw on the battery compartment cover.



MAINTENANCE

Your scope, though amazingly tough, is a precision instrument that deserves reasonable cautious care.

- When cleaning the lens, first blow away any dirt and dust, or use a soft lens brush. Fingerprints and lubricants can be wiped off with lens tissue, or soft clean cotton cloth, moistened with lens cleaning fluid.
- All moving parts of the scope are permanently lubricated. Do not try to lubricate them.
- No maintenance is needed on the scope's outer surface, except to occasionally wipe off dirt or fingerprints with a soft cloth.
- Use lens covers whenever convenient.

STORAGE

Avoid storing the scope in hot places, such as the passenger compartments of vehicles on hot days. The high temperatures could adversely affect the lubricants and sealants. A vehicle's trunk, a gun cabinet, or a closet is preferable. Never leave the device where direct sunlight can enter either the optics lens.